



# KORE3 Industries LLC

info@kore3.com

800.357.5467

## Rear GM 10/12-Bolt Brake Fitment Template Instructions: (DOC0009.PDF)

1. Print drawing and verify scale with the horizontal and vertical rulers given in "inches".
2. Paste to cardboard or paperboard.
3. Cut along dotted line around outside profile of the rotor and caliper. Double check your wheel hub diameter.
4. Position template in wheel and check clearance. If the edge of the template is within .100" of the wheel at any point, we recommend fitting with actual parts.

NOTE: This drawing is to aid in application fitment and is accurate to the best of our knowledge.

It is your responsibility to determine whether or not your application requires the use of wheel spacers, and what thickness.

If you have any questions with the use of this template or regarding your application, please contact KORE3 Industries at info@kore3.com or toll free at 800.357.5467.

INSERT INTO WHEEL HUB AND CHECK CLEARANCE.

φ2.776

